

	TYPE	MODEL
 	smartphone	iPhone 4 iPhone 4S iPhone 5 iPhone 5S iPhone 5C iPhone 6 iPhone 6 Plus iPod touch (5th generation)
	tablet	iPad 2 Wi-Fi / Wi-Fi+3G iPad 3 Wi-Fi / Wi-Fi+Cellular iPad mini Wi-Fi / Wi-Fi+Cellular iPad mini 3 Wi-Fi / Wi-Fi+Cellular iPad Retina Display (3rd and 4th generation) Wi-Fi / Wi-Fi+Cellular iPad Air Wi-Fi / Wi-Fi+Cellular iPad Air 2 Wi-Fi / Wi-Fi+Cellular

Updates to our apps will be available provided that the device is updated with iOS 7.0 or higher. Wi-Fi model locates your GPS position only if Wi-Fi is connected. Wi-Fi+3G model operates similar to iPhone with regard to GPS capability.

	TYPE	MODEL
 ANDROID  		tablet Iconia Tab A501
		tablet EeePad Transformer TF101 Transformer Pad Infinity – TF700T Google Nexus 7 (1st and 2nd generation)
		smartphone Incredible
		tablet Xoom MZ604
		tablet NAVIOTAB
		smartphone Forward Next Forward Prime
		smartphone Galaxy S II Galaxy S III Galaxy S4 Galaxy S5 Galaxy S6 Galaxy Note GT-N7000
		tablet Galaxy Tab 10.1 GT-P7500 Galaxy Note 10.1

Navionics apps are designed to load and operate correctly with all phones and tablets with an Android OS 4.0 or higher. For models not listed, it is likely that the app will work but we cannot guarantee flawless operation on non-certified devices.